

S mode (AT): Select this mode while riding in AT MODE when you need more power, such as when overtaking, climbing hills, pulling away.

MT MODE: MT MODE (6-speed manual operation) You can choose between 6 gears in this mode.

Changing between Neutral and AT/MT

Changing from Neutral (N) to AT MODE
Press the D/S side of the N-D switch (1). The D mode indicator comes on, "1" is shown in the gear position indicator and first gear is selected.

Changing from AT or MT MODE to Neutral

Press N on the N-D switch (2).

Changing between D mode and S mode while in AT MODE

Press the D/S side of the N-D switch. The S or D mode indicator comes on (3, 4).

Changing between AT MODE and MT MODE

Press the AT/MT switch (5).

The S or D indicator goes out while MT MODE is selected (6).

