## **OPERATION**

	page	
MOTORCYCLE SAFETY	35	Right Handlebar Controls
Safe Riding Rules	36	Left Handlebar Controls
Protective Apparel		
Modifications	37	FEATURES
Loading and Accessories		(Not required for operation)
	37	Steering Lock
PARTS LOCATION	38	Helmet Holder
Instruments and Indicators	39	Seat/Document Bag
	40	Storge Compartment for
MAJOR COMPONENTS		U-shaped Anti-theft Lock
(Information you need to operate	41	Rear Seat Cover
this motorcycle)	43	Middle Fairing
Suspension	44	Side Cover
Brakes		
Clutch	45	OPERATION
Coolant	45	Pre-ride Inspection
Fuel	46	Starting the Engine
Engine Oil	50	Running-in
Tubeless Tyres	51	Riding
	53	Braking
ESSENTIAL INDIVIDUAL	54	Parking
COMPONENTS	55	Anti-theft Tips
Ignition Switch		-
	MOTORCYCLE SAFETY Safe Riding Rules Protective Apparel Modifications Loading and Accessories  PARTS LOCATION Instruments and Indicators  MAJOR COMPONENTS (Information you need to operate this motorcycle) Suspension Brakes Clutch Coolant Fuel Engine Oil Tubeless Tyres  ESSENTIAL INDIVIDUAL COMPONENTS	MOTORCYCLE SAFETY       35         Safe Riding Rules       36         Protective Apparel       37         Modifications       37         Loading and Accessories       37         PARTS LOCATION       38         Instruments and Indicators       39         MAJOR COMPONENTS       40         MAJOR COMPONENTS       41         this motorcycle)       43         Suspension       44         Brakes       Clutch       45         Coolant       45         Fuel       46         Engine Oil       50         Tubeless Tyres       51         ESSENTIAL INDIVIDUAL       54         COMPONENTS       55