

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH	6	12	18	24	30	36			
			EVERY 1,000 km (600 mi) I, L								108-112
DRIVE CHAIN					I		I		I	113	
DRIVE CHAIN SLIDER					I		I		I	113	
BRAKE FLUID		NOTE (3)			I	I	R	I	I	R	31-33
BRAKE PAD WEAR					I	I	I	I	I	I	122
BRAKE SYSTEM				I		I		I		I	31-33, 124
* BRAKE LIGHT SWITCH						I		I		I	130
* HEADLIGHT AIM						I		I		I	-
CLUTCH SYSTEM						I		I		I	34
CLUTCH FLUID		NOTE (3)			I	I	R	I	I	R	34
SIDE STAND						I		I		I	115
* SUSPENSION						I		I		I	114
* NUTS, BOLTS, FASTENERS				I		I		I		I	-
** WHEELS/TYRES						I		I		I	-
** STEERING HEAD BEARINGS				I		I		I		I	-