


## ■ Rear Turn Signal Bulb

1. Remove the rear seat. ► P. 64
2. Remove the bolts.
3. Remove the rear cowl by pulling backward carefully.



4. Remove the turn signal cover by releasing the tabs carefully.

