



Digital clock

Shows hour and minute. To adjust time, proceed as follows :

1. Turn the ignition switch ON.
2. Press and hold both the TEMP (1) and TRIP (2) button for more then 2 seconds. The display will be set mode.
3. To set the hour, press and release the TEMP button (1) until the desired hour and AM/PM setting are displayed.
4. To set the minute, press and release the TRIP button (2) until the desired minute is displayed. The minute display will return to "00" when "60" is resched without affecting the hour display.
5. Turn the ignition switch OFF to lock in the time display. (Or wait 30 seconds; the display will stop flashing automatically.)



- (1) TEMP button
- (2) TRIP button