


Front Turn Signal Bulb

1. Remove the front turn signal lens (1) by removing the screw (2).
2. Turn the socket (3) 90° counterclockwise and remove it.
3. Pull out the bulb (4) without turning.
4. Install a new bulb in the reverse order of removal.



(1) Turn signal lens
(2) Screw

(3) Socket
(4) Bulb