


## Seat/Document Bag/Fairing Pockets

The document bag is located under the seat to store the owner's manual (3) and other documents. Release the helmet holder with the ignition key (1) and pull the seat lock levers (2) backward. Then remove the seat (4) by lifting and sliding it backward.

The fairing pockets (5) can be used by unsnapping the cover (6).



## Siège/logement à documents/Poches de carénage

Le logement à documents se trouve sous le siège et il peut recevoir le manuel du conducteur et d'autres documents. Libérer le porte-casque à l'aide de la clé de contact (1) et tirer le levier de verrouillage (2) du siège vers l'arrière. Enlever le siège (4) en le soulevant et en le glissant vers l'arrière.

Il est possible d'utiliser les poches de carénage (5) en ouvrant le couvercle (6).

