## NOTE:

\* Do not open the throttle when starting the engine with the choke open. This will lean the mixture, resulting in hard starting.

## **CAUTION:**

\* The red oil pressure warning light should go off a few seconds after the engine starts. If the light stays on, stop the engine immediately and check engine oil level. Operating the engine with insufficient oil pressure can cause serious engine damage.