


The engine number (3) is stamped on the right side of the crankcase.

ENGINE NO. _____




(3) Engine number

COLOR LABEL

The color label (1) is attached to the rear fender below the seat. It is helpful when ordering replacement parts. Record the color and code here for your reference.

COLOR _____

CODE _____



(1) Color label