

INSTRUMENTS AND INDICATORS

The indicators and warning lights are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Speedometer
- (2) Odometer
- (3) Left turn signal indicator
- (4) Coolant temperature gauge
- (5) Right turn signal indicator
- (6) Tachometer
- (7) Tachometer red zone
- (8) Tripmeter
- (9) Oil pressure warning light
- (10) High beam indicator
- (11) Neutral indicator
- (12) Tripmeter reset knob

