

## LEFT HANDLEBAR CONTROLS


### Headlight Dimmer Switch (1)

Select HI for beam, LO for low beam.

### Turn Signal Switch (2)

Move to L to signal a left turn, R to signal a right turn. Press to turn signal off.

〈 Except AR type 〉



- (1) Headlight dimmer switch
- (2) Turn signal switch

### Horn Button(3)


Press the button to sound the horn.

### Passing Light Control Switch (4)

〈 AR type only 〉

When this switch is pressed, the headlight flashes on to signal approaching cars or when passing.

〈 AR type 〉



- (3) Horn button
- (4) Passing light control switch