

ITEM	FREQUENCY	WHICHEVER →		ODOMETER READING [NOTE (1)]								REFER TO PAGE
		COMES	x 1,000 km	1	6	12	18	24	30	36		
		FIRST ↓	x 1,000 mi	0.6	4	8	12	16	20	24		
		NOTE	MONTH		6	12	18	24	30	36		
DRIVE CHAIN				EVERY 1,000 km (600 mi) I, L								61-66
BRAKE FLUID	(NOTE 4)			I	I	R	I	I	R		14-15	
BRAKE SHOE/PAD WEAR				I	I	I	I	I	I		68, 69	
BRAKE SYSTEM			I		I		I		I		14-17	
* BRAKE LIGHT SWITCH					I		I		I		77	
* HEADLIGHT AIM						I		I		I	--	
CLUTCH SYSTEM			I	I	I	I	I	I	I	I	18-19	
SIDE STAND						I		I		I	67	
* SUSPENSION						I		I		I	--	
* NUTS, BOLTS, FASTENERS			I		I		I		I		--	
** WHEELS/TYRES			I	I	I	I	I	I	I	I	--	
** STEERING HEAD BEARINGS			I		I		I		I		--	