


Controls & Features


Push the button (2) to select the “ODO”, “TRIP 1” or “TRIP 2” mode.

To reset the tripmeter, push and hold the button with the display in the “TRIP 1” or “TRIP 2” mode.

FRONT



- (1) odometer/tripmeter display
- (2) odometer/tripmeter select and reset button



- (3) odometer
- (4) tripmeter 1
- (5) tripmeter 2
- (6) tripmeter reset