

manuals	194
warranty	198
shifting gears	40
side cover removal.....	71
side stand	124
side stand ignition cutoff system	35
spark knock.....	73
spark plugs.....	104
specifications	177
speedometer	15
stand, side	124
start button	19
starting,	
engine.....	35
troubleshooting	147
steering lock.....	44
stop switch, engine	20
stopping engine.....	39
storage,	
motorcycle	138

owner's manual	69
compartment	70
suspension,	
rear suspension adjustment	108
rear suspension spring pre-load.....	108
switch,	
headlight dimmer.....	20
ignition.....	18
turn signal	21

T

theft prevention tips.....	46
throttle.....	96
tires,	
air pressure.....	117
flat.....	152
replacing	121

(cont'd)