

## INSTRUMENTS AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Speedometer
- (2) Neutral indicator
- (3) PGM-FI malfunction indicator lamp (MIL)
- (4) High beam indicator
- (5) Low oil pressure indicator
- (6) Tachometer
- (7) Tachometer red zone
- (8) Coolant temperature indicator
- (9) Turn signal indicator
- (10) Fuel indicator
- (11) Multi-function display
- (12) Multi-function select and reset button

