

Starting Procedure

- When the engine is cold:
 1. Check the engine stop switch is in RUN position.
 2. Check the fuel cock lever is in ON position.
 3. Turn the ignition ON.
 4. Shift the gear change pedal to neutral position and check that the neutral indicator is ON.
 5. Pull the choke lever all the way back.
 6. Close the throttle and press the starter button.
 7. When the engine starts, gradually push the choke lever forward and warm up the engine until the rpm stabilizes, then push the choke lever all the way forward.
 8. Check the side stand is retracted before riding.
- Refer to p.79 if the engine fails to start.

