

INSTRUMENTS AND INDICATORS

The indicators are contained on the fuel tank. Their functions are described in the tables on the following pages.

- (1) Speedometer
- (2) Odometer/tripmeter display
- (3) Fuel indicator
- (4) Neutral indicator
- (5) Low oil pressure indicator
- (6) PGM-FI indicator
- (7) Turn signal indicator
- (8) Coolant temperature indicator
- (9) High beam indicator
- (10) Odometer/tripmeter select and reset button

