

## Engine Idle Speed

---

3. Shift into neutral. Start the engine.
4. Adjust idle speed with the throttle stop screw (1).

Idle speed (in neutral):

$800 \pm 100$  rpm