

4. Refill each fork leg with 4.9 oz. (145 cc) of premium quality automatic transmission fluid (ATF).
5. Install filler plugs, handlebars, and remove block from under motorcycle.

Rear Suspension Inspection

Check the rear suspension periodically by careful visual examination. Note the following items.

1. Rear fork bushing—this can be checked by pushing hard against the side of the rear wheel while the motorcycle is on a support block and feeling for looseness of the fork bushings.
2. Check side stand spring for damage.
3. Check all suspension components attachment points for security of their respective fasteners.

NOTE : If any of the above components appear damaged or worn, consult your Honda dealer for further inspection.