

MAINTENANCE SCHEDULE

Perform Pre-Ride Inspection (Page 23) at each scheduled maintenance period.

I: Inspect, Clean, Adjust, Lubricate or Replace if Necessary.

C: Clean. R: Replace. A: Adjust.

ITEM		FREQUENCY	WHICHEVER COMES FIRST → EVERY	ODOMETER READING [NOTE (5)]				Refer to
				600mi (1,000km)	3,600mi (6,000km)	7,200mi (12,000km)	10,800mi (18,000km)	
EMISSION RELATED ITEMS		ENGINE OIL	YEAR	R	REPLACE EVERY 1,800 mi (3,000km)			Page 42
	*	ENGINE OIL FILTER SCREEN				C		
		CRANKCASE BREATHER	NOTE (1)		C	C	C	Page 45
		AIR CLEANER	NOTE (2)		C	C	C	Page 44
	*	FUEL LINES			I	I	I	
		SPARK PLUG			I	R	I	Page 43
	*	VALVE CLEARANCE		I	I	I	I	
	*	STARTER DECOMPRESSOR		I	I	I	I	
	*	CAM CHAIN TENSION		A	A	A	A	
	*	THROTTLE OPERATION		I	I	I	I	
	*	CARBURETOR IDLE SPEED		I	I	I	I	
	*	CARBURETOR CHOKE			I	I	I	
	**	BALANCER CHAIN TENSION				A		