

MAINTENANCE SCHEDULE

Perform the Pre-ride Inspection (page 68) at each scheduled maintenance period.

I : INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY.

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEM	FREQUENCY	WHICHEVER COMES FIRST → ↓	ODOMETER READING [NOTE (4)]						REFER TO
			1,000 km (600 mi)	6,000 km (3,600 mi)	12,000 km (7,200 mi)	18,000 km (10,800 mi)	24,000 km (14,400 mi)	30,000 km (18,000 mi)	
* FUEL LINES				I	I	I	I	I	
* FUEL STRAINER			C	C	C	C	C	C	
* THROTTLE OPERATION			I	I	I	I	I	I	
* CARBURETOR-CHOKE				I	I	I	I	I	
AIR CLEANER		NOTE (1)		C	C	C	C	C	Page 110
CRANKCASE BREATHER		NOTE (2)		C	C	C	C	C	Page 164
SPARK PLUGS				I	R	I	R	I	Page 106
* VALVE CLEARANCE			I	I	I	I	I	I	Page 112
ENGINE OIL		YEAR R	R	REPLACE EVERY 3,000 km (1,800 mi)					Page 100
ENGINE OIL FILTER			R	R	R	R	R	R	Page 104
* STARTER DECOMPRESSOR			I	I	I	I	I	I	
* CARBURETOR-IDLE SPEED			I	I	I	I	I	I	Page 122