

ITEM	FREQUENCY	WHICHEVER COMES FIRST → ↓	ODOMETER READING [NOTE (4)]						REFER TO
			1,000 km (600 mi)	6,000 km (3,600 mi)	12,000 km (7,200 mi)	18,000 km (10,800 mi)	24,000 km (14,400 mi)	30,000 km (18,000 mi)	
		EVERY							
DRIVE CHAIN		NOTE (3)	I, L, EVERY 1,000 km (600 mi)						Page 126
DRIVE CHAIN SLIPPER			I	I	I	I	I	I	Page 128
BATTERY		MONTH 1	I	I	I	I	I	I	Page 166
BRAKE FLUID		MONTH 1 2 YEARS *R	I	I	I	*R	I	I	Page 138
BRAKE PAD/SHOE WEAR			I	I	I	I	I	I	Page 144, 148
BRAKE SYSTEM			I	I	I	I	I	I	
* BRAKE LIGHT SWITCH			I	I	I	I	I	I	
* HEADLIGHT AIM			I	I	I	I	I	I	
CLUTCH			I	I	I	I	I	I	Page 124
SIDE STAND			I	I	I	I	I	I	Page 150
* SUSPENSION			I	I	I	I	I	I	
* NUTS, BOLTS, FASTENERS		NOTE (3)	I	I	I	I	I	I	
** WHEELS/SPOKES		NOTE (3)	I	I	I	I	I	I	
** STEERING HEAD BEARING			I		I		I		

* SHOULD BE SERVICED BY AN AUTHORIZED HONDA DEALER, UNLESS THE OWNER HAS PROPER TOOLS AND SERVICE DATA AND IS MECHANICALLY QUALIFIED. REFER TO THE OFFICIAL HONDA SHOP MANUAL.

** IN THE INTEREST OF SAFETY, WE RECOMMEND THESE ITEMS BE SERVICED ONLY BY AN AUTHORIZED HONDA DEALER

NOTES: (1) Service more frequently when riding in dusty areas.

(2) Service more frequently when riding in rain or at full throttle.

(3) Service more frequently when riding OFF-ROAD.

(4) For higher odometer reading, repeat at the frequency interval established here.