


## Carburetor

Idle Speed:

### NOTE:

- Do not attempt to compensate for faults in other systems by carburetor adjustment. See your authorized Honda dealer for regularly scheduled carburetor adjustments.
  - The engine must be warm for accurate idle adjustment.
1. Warm up the engine, shift to neutral and hold the motorcycle upright.
  2. Adjust idle speed with the throttle stop screw (1).

IDLE SPEED:  $1300 \pm 100$  rpm



---

## Carburateur

Régime de ralenti:

### NOTE:

- Ne pas essayer de compenser des défauts d'autres systèmes par des réglages du carburateur. S'adresser au concessionnaire Honda autorisé pour les réglages du carburateur programmés.
  - Pour que le régime de ralenti puisse être précis, le moteur doit être chaud.
1. Echauffer le moteur, passer au point mort et maintenir la moto à la verticale.
  2. Régler le régime de ralenti à l'aide de la vis butée de boisseau (1).
- REGIME DE RALENTI:  $1\ 300 \pm 100$  tr/mn