

- Stop/Taillight Bulb
  1. Remove the two screws (1).
  2. Pull off the lens (2) and replace the bulb
  (3) with a new one.







(3) Bulb

(1) Screws

(2) Lens