

INSTRUMENTS

TELL TALE LAMPS

Direction Indicator

When the Direction Indicator switch is activated, the Tell Tale Lamp will illuminate and flash.

Hi-Beam Lamp

When Hi-Beam is selected, the blue Hi-Beam Tell Tale Lamp will illuminate.

Neutral Lamp

When the Ignition switch is in the "ON" position, the Green Neutral Lamp will illuminate.

