




Crankcase Breather (California only)

Refer to *Safety Precautions* on page 45.

Service more frequently if your motorcycle is ridden in the rain or often at full throttle. Service the breather if you can see deposits in the transparent section of the drain tube.

LEFT SIDE



(1) crankcase breather tube plug

1. Remove the crankcase breather tube plug (1) from the tube and drain deposits.
2. Reinstall the crankcase breather tube plug.

