

03/05/20 10:09:42 31KCY680_097

Suspension

Refer to *Safety Precautions* on page 45.

Loose, worn, or damaged suspension components may adversely affect the handling and stability of your motorcycle. If any suspension components appear worn or damaged, see your Honda dealer for further inspection. Your dealer is qualified to determine whether or not replacement parts or repairs are needed.

Front Suspension Inspection

FRONT

A line drawing of the front suspension assembly of a motorcycle. Four arrows point to specific mounting bolts on the fork legs and the front fork bridge. Each arrow is labeled with the number '(1)'. The diagram shows the fork tubes, the front fork bridge, and the mounting points where the fork tubes meet the frame.

(1) mounting bolts

1. Check fork operation. Pull the front brake lever in, to lock the brake. Then pump up and down on the fork legs several times. The suspension should function smoothly. There should be no oil leakage.

88 Servicing Your Honda