



# Suspension

## Compression Damping

Compression damping affects how quickly the fork compresses.


The fork compression damping adjuster has at least 14 positions (clicks). Turning the adjuster screw one full turn advances the adjuster 4 positions.

Always start with the full hard position when adjusting damping.



*To adjust to the standard position:*

LEFT FRONT



(1) compression damping adjuster



(cont'd)

