



**Wire harness inspection**

Check for continuity of the Black/Blue wire between the fan motor relay 2P (Natural) connector and ECM 32P (Black) connector.  
There should be continuity.  
If there is no continuity, repair or replace the wire harness.

**Chapter lights / instruments / switches (ED / 2E)**

**System location**

