


Date

To set the date: **↔P.21**

Clock (12-hour display)


To set the clock: **↔P.22**



Fuel gauge

Remaining fuel when only 1st (E) segment starts flashing approximately: 1.0 L (0.26 US gal, 0.22 Imp gal)

If the fuel gauge indicator flashes in a repeat pattern or turns off: **↔P.100**



Speedometer