

Instruments (Continued)

Display Setting

Following items to change sequentially.

- Date setting
- Clock setting
- Backlight brightness adjustment
- Activating/deactivating of tripmeter A and average fuel mileage A automatic reset mode

The following moves the ordinary display at display setting.

- The switch is not pressed for about 30 seconds
 - Turn the ignition switch to the **O** (Off) position and then to the **I** (On) position
- To complete the setting for date and clock, it is necessary to finalise the minute in the clock setting or turn the ignition switch to the **O** (Off) position.

