


Changing the Answer Back Buzzer Sound Pattern


You can select 3 buzzer sound patterns.

- 1 Make sure that the Honda SMART Key system is active. **▶P.30**
 - 2 Remove the battery cover. **▶P.80**
 - 3 Push the ignition switch to authenticate the Honda SMART Key system. **▶P.34**
 - 4 Connect the EM mode coupler provided in the tool kit to the EM mode connector. **▶P.107**
- ▶ The Honda SMART Key indicator and ignition switch ring go off.

Answer back button



Ignition switch



Ignition switch ring

5 Push the ignition switch 1 time.

6 Repeat the following 3 times:

Press the answer back button on the Honda SMART Key 3 times and the ignition switch 1 time.

- ▶ When the answer back button is pressed, the Honda SMART Key LED comes on. Make sure the LED goes off before pressing the button again.
- ▶ If the answer back button or ignition switch is not pressed for 1 minute, the Honda SMART Key indicator starts blinking and this mode will be cancelled. If so, remove the EM mode coupler, return to 3 and follow the procedure again.