

# Maintenance Schedule

## Maintenance

Items	Pre-ride Check ➡ P. 69	Frequency *1											Annual Check	Regular Replace	Refer to page	
		x 1,000 km	1	6	12	18	24	30	36							
		x 1,000 mi	0.6	4	8	12	16	20	24							
Fuel Line			I	I	I	I	I	I	I	I	I	I	I			-
Fuel Level	I															-
Throttle Operation	I		I	I	I	I	I	I	I	I	I	I	I			89
Air Cleaner *2																-
Crankcase Breather *3			C	C	C	C	C	C	C	C	C	C	C			-
Spark Plug			I	R	I	I	I	I	I	R	I	I	R			-
Valve Clearance			I	I	I	I	I	I	I	I	I	I	I			-
Engine Oil	I		R	R	R	R	R	R	R	R	R	R	R			82
Engine Oil Strainer Screen				C									C			
Engine Idle Speed		I	I	I	I	I	I	I	I	I	I	I	I			-
Radiator Coolant *4	I			I									I	3 Years		84
Cooling System				I									I			-

### Maintenance Level

 : Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled.

 : Technical. In the interest of safety, have your vehicle serviced by your dealer.

### Maintenance Legend

**I** : Inspect (clean, adjust, lubricate, or replace, if necessary)

**R** : Replace

**C** : Clean