



## STEERING STEM

### FORK BRIDGE REMOVAL


Remove the headlight and headlight case (Page 10-3).

Remove the handlebar (Page 10-7).

Remove the front wheel (Page 10-10).



Remove the headlight case bracket. (Page 10-6).



Remove the front fender.

