



INTRODUCTION

This addendum contains service information for the 1983 ATC250R. Refer to the base shop manual for all service information not included in this addendum.

All information, illustrations, directions and specifications included in this publication are based on the latest product information available at the time of approval for printing.

Honda Motor Co., LTD. reserves the right to make changes at any time without notice and without incurring any obligation whatever. No part of this publication may be reproduced without written permission.

HONDA MOTOR CO., LTD.
Service Publications Office

CONTENTS

- 1. GENERAL INFORMATION** 18-2
 - Specifications 18-2
 - Torque Values 18-4
 - Cable and Harness Routing 18-5
 - Wiring Diagram 18-7
- 2. MAINTENANCE** 18-8
 - Air Cleaner 18-8
 - Throttle Operation 18-8
 - Drive Chain 18-9
 - Rear Suspension 18-10
- 3. FUEL SYSTEM** 18-11
 - Fuel Tank 18-11
 - Air Cleaner Case 18-12
 - High Altitude Adjustment 18-12
- 4. ENGINE REMOVAL/INSTALLATION** 18-13
 - Engine Removal 18-13
 - Engine Installation 18-15
- 5. FRONT WHEEL/SUSPENSION/STEERING** 18-16
 - Service Information 18-16
 - Headlight 18-18
 - Handlebar 18-19
 - Front Wheel 18-19
 - Front Fork 18-23
 - Steering Stem 18-28
- 6. REAR SUSPENSION** 18-30
 - Service Information 18-30
 - Shock Absorber 18-31
 - Swing Arm 18-39

