




## 4. ENGINE REMOVAL/INSTALLATION

### ENGINE REMOVAL

Remove the components shown in this photo of the right side.



Remove the parts shown in this photo of the left side.

