


Stopping the Anti-theft Alarm System

- 1 To cancel the anti-theft alarm system, do one of the following:
 - Press the alarm button on the Honda SMART Key.
 - Unlock the ignition switch. **▶P.34**
 - Press the seat open button while the Honda SMART Key is in the operating range. **▶P.31**
- 2 Make sure that the turn signal light and alarm indicator blink 2 times, and the buzzer rings 2 times. This indicates that the anti-theft alarm system is cancelled.

Alarm button




Stopping the Anti-theft Alarm Activation

- To stop the anti-theft alarm activation, do one of the following:
- Press the alarm button on the Honda SMART Key.
 - Press the answer back button on the Honda SMART Key.
 - Unlock the ignition switch. **▶P.34**
 - Press the seat open button. **▶P.52**

After stopping the anti-theft alarm activation, the anti-theft alarm system will be cancelled.

Alarm button



Answer back button

