

Answer Back System (Continued)

- 7 Press the answer back button to select from 3 buzzer sound patterns.
The Honda SMART Key indicator and ignition switch ring come on while setting.
- 8 Wait for about 10 seconds until the ignition switch ring starts blinking. The sound pattern is set.
- 9 Remove the EM mode coupler from the EM mode connector to finish setting.
 - ▶ The sound pattern is also set if you remove the EM mode coupler before the ignition switch ring starts blinking.
- 10 Store the EM mode coupler on the battery cover. Reinstall the parts in reverse order.

Temporary Silence Mode

Temporary silence mode is the immediate way to turn off the answer back system buzzer sound.

Enable:

Press and hold the answer back button for about 2 seconds. The Honda SMART Key LED changes to red.

Disable:

Re-press and hold the answer back button for about 2 seconds. The Honda SMART Key LED changes to green.