


Storage Equipment

Helmet holder

The helmet holders are located under the seat.

- ▶ Use the helmet holders only when parked.



Seat Open

The seat open button can be operated when the Honda SMART Key is in the operating range (P. 31) and the ignition switch is in the OFF or **L** (Lock) position.

Press the seat open button and open the seat.

- ▶ If the battery does not have enough voltage to start the engine, the seat may not open.

Seat Close

Close the seat and push down on the rear of the seat until it locks. Make sure that the seat is locked securely to pull it up lightly.

⚠WARNING

Riding with a helmet attached to the holder can interfere with your ability to safely operate the motorcycle and could lead to a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.