


Center Cover



Removal

Remove the center cover by removing the screw.

Installation

1. Open the left and right body covers slightly, then install the center cover while aligning each tab and slit.
2. Install and tighten the screw.