

# Troubleshooting

<b>Engine Will Not Start</b> .....	P. 102
<b>Warning Indicators On or Flashing</b> .....	P. 103
PGM-FI (Programmed Fuel Injection)	
Malfunction Indicator Lamp (MIL).....	P. 103
ABS (Anti-lock Brake System) Indicator .....	P. 104
Honda SMART Key Indicator .....	P. 105
<b>Other Warning Indications</b> .....	P. 106
Fuel Gauge Failure Indication.....	P. 106
<b>When the Honda SMART Key System Does Not Operate Properly</b> .....	P. 107
<b>Unlock the Ignition Switch in an Emergency</b> .....	P. 109
<b>Tire Puncture</b> .....	P. 112
<b>Electrical Trouble</b> .....	P. 117
Battery Goes Dead.....	P. 117
Burned-out Light Bulb .....	P. 117
Blown Fuse.....	P. 119
<b>Unstable Engine Operation Occurs Intermittently</b> .....	P. 120