

Parking

- Park on a firm, level surface.
 - If you must park on a slight incline or loose surface, park so that the vehicle cannot move or fall over.
 - Make sure that high-temperature parts cannot come into contact with flammable materials.
 - Do not touch the engine, muffler, brakes and other high-temperature parts until they cool down.
 - To reduce the likelihood of theft, always lock the handlebar, lock the ignition switch (➔ P. 35) and leave your vehicle while taking the Honda SMART Key with you. Deactivate the Honda SMART Key system if necessary. ➔ P. 30
- Use of an anti-theft device is also recommended.
- Also set the anti-theft alarm system.

Parking with the Center Stand

1. Stop the engine.
2. To lower the center stand, stand on the left side of the vehicle.
Hold the left handle grip and the center stand grip.
Press down on the tip of the center stand with your right foot and, simultaneously, pull up and back.
3. Turn the handlebar fully to the left.

