



Indicators

If one of these indicators does not come on when it should, have your dealer check for problems.

 **Turn signal indicator**

 **High beam indicator**

Alarm indicator

Anti-theft Alarm System:  **P.37**

 **Honda SMART Key indicator**

Comes on when vehicle and Honda SMART Key verification is complete, and the ignition switch can be operated. Goes off when the ignition switch is turned to the ON position.

When the Honda SMART Key Indicator Flashes:  **P.105**

