

## **M**

### **Maintenance**

Fundamentals .....	61
Importance .....	55
Record .....	60
Safety .....	56
Schedule.....	57
<b>Maximum Weight Capacity</b> .....	14, 143
<b>Modifications</b> .....	13

## **N**

<b>Neutral Indicator</b> .....	25
--------------------------------	----

## **O**

<b>Odometer</b> .....	20, 124
<b>Oil</b>	
Engine .....	67, 81
<b>ON/OFF Button</b> .....	27
<b>Oxygenated Fuels</b> .....	137

## **P**

<b>Parking</b> .....	11
<b>Parts Location</b> .....	18

## **PGM-FI (Programmed Fuel Injection)**

<b>Malfunction Indicator Lamp (MIL)</b> ....	25, 103
<b>Protective Apparel</b> .....	8

## **R**

### **Recommended**

Engine Oil .....	67, 144
Fuel .....	50
<b>Refueling</b> .....	50

### **Removal**

Battery.....	76
Center Cover.....	78

<b>Repair Kit</b> .....	112
-------------------------	-----

<b>Reporting Safety Defects</b> .....	142
---------------------------------------	-----

<b>Riding Precautions</b> .....	9
---------------------------------	---

<b>Right Side Cover</b> .....	53
-------------------------------	----

## **S**

<b>Safety Guidelines</b> .....	3
--------------------------------	---

<b>Safety Labels</b> .....	6
----------------------------	---

<b>Safety Precautions</b> .....	8
---------------------------------	---

<b>Shifting Gears</b> .....	49
-----------------------------	----

<b>Spark Plug</b> .....	79
-------------------------	----

<b>Specifications</b> .....	143
-----------------------------	-----