


Storage Equipment


Helmet holder

Helmet holders are located on the left side below the seat and under the seat. Use the helmet holders only when parked.

Helmet holder



- ▶ Insert the ignition key and turn it clockwise to unlock. Hang your helmet on the holder hook. Turn the key counterclockwise to lock the holder hook and then remove the key.



Removing the Seat → P.53

⚠ WARNING

Riding with a helmet attached to the holder can interfere with the rear wheel or suspension and could cause a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.