

Inspecting the Brake Pads

Check the condition of the brake pad groove wear indicators.

Front

(CB1100)

The pads need to be replaced if a brake pad is worn to the bottom of the groove.

(CB1100A)

The pads need to be replaced if a brake pad is worn to the groove.

Rear

The pads need to be replaced if a brake pad is worn to the groove.

1. Front

(CB1100)

Inspect the brake pads from in front of the brake caliper.

(CB1100A)

Inspect the brake pads from the bottom of the brake caliper.

► Always inspect both left and right calipers.

