

Instruments *(Continued)*

Order of priority for the color:



Color OFF mode

All color mode is deactivated. The multi color line will light if the time sign setting, fuel sign setting or switch sign setting is On, even when the color OFF mode is selected.

Rev up linkage mode (white color mode)

When the number of engine revolution reaches the shift up point you have set, the color of the multi color line blinks in white. This informs you of the indication to shift up.

Example: When shift up rev setting is 10,000 r/min (rpm)
and shift width setting is 200 r/min (rpm).

multi color line	r/min (rpm)
Blinks	9,600
Blinks fast	9,800
Blinks faster	10,000

To set the shift up rev setting:  **P.42** / **To set the shift width setting:**  **P.43**