

Rev up linkage mode (color mode)

When the number of engine revolution reaches shift up point you have set, the color of the multi color line will change. This informs you of the indication to shift up.

Example: When shift up rev setting is 10,000 r/min (rpm)
and shift width setting is 200 r/min (rpm).

multi color line	r/min (rpm)
Yellow	9,600
Amber	9,800
Pink	10,000

To set the shift up rev setting:  **P.42** / **To set the shift width setting:**  **P.43**

ECO mode

Depending on fuel consumption, the multi color line will change.

If fuel consumption is improved, the color of the multi color line will change to Aqua.

Further, when fuel consumption is improved, it will turn Green.

- ▶ The ECO mode includes Rev up linkage mode (color mode).