

Start Button	26
Starting the Engine	28
Steering Lock	27
Stopping Engine	110
Storage	
Compartment	31
Owner's Manual	31
Storing Your Motorcycle	114
Switches	26
T	
Tachometer	18
Throttle	78
Tires	
Air Pressure	50
Puncture	91
Replacing	53, 91
Transporting Your Motorcycle	115
Tripmeter	18
Troubleshooting	86
Turn Signal Indicators	25

V

Vehicle Identification Number	117
-------------------------------------	-----

W

Warning Indicators On	89
Warranty Coverage and Service	126
Washing Your Motorcycle	111
Weight Limit	15, 131

Wheels

Front Removal	92
Rear Removal	98