


### N Neutral indicator

Comes on when the transmission is in Neutral.



### High beam indicator



### High coolant temperature indicator

Comes on briefly when the ignition switch is turned on.

**If it comes on while riding:** ( P81)



### ABS (Anti-lock Brake System) indicator CB300FA only

Comes on when the ignition switch is turned on. Goes off when your speed reaches approximately 6 mph (10 km/h).

**If it comes on while riding:** ( P82)